

Motorola Evolve button integration with GroupTalk



Requirements

GroupTalk for Android v3.7.14+

Disable Wave

If the phone comes preinstalled with the Wave app it needs to be disabled to prevent it from launching the app when clicking the PTT button.

Android Settings > Apps & notifications > See all apps > WAVE > DISABLE.

The following buttons are supported by default in GroupTalk

- PTT button
- SOS button
- Next/Previous channel

Side buttons can be configured as follows

There are three buttons on the side of the device. Button 1 and 3 can be made to trigger functions in GroupTalk if they are mapped to “Send to an application” at:

Settings > Buttons > Programmable Buttons

- Button 1 [short press] is mapped to Function 1 in GroupTalk (default queue)
- Button 1 [long press] is mapped to Function 2 in GroupTalk
- Button 3 [short press] is mapped to Function 3 in GroupTalk
- Button 3 [long press] is mapped to Function 4 in GroupTalk

To map Function 1-4 to various functions in GroupTalk, go to

GroupTalk app > Settings > Configure Button > FN button #1-4

Available GroupTalk functions that can be mapped are: queue, repeat message, toggle group, transmit tone, toggle silent mode, volume up/down.

Button 2 is used to turn on / off the screen and can not be mapped to GroupTalk functions.

Microphone levels on the device can be a bit low. Try setting the Microphone gain to +10dB in the GroupTalk settings.